

## Using THE C9 TOUCH to smooth, flick, curl or straighten The Worlds First Fully Automatic Styling Iron

- Simply plug into the mains and start using THE C9 TOUCH, it will automatically activate and instantly reach the optimum operating temperature, 195c, once the plates are closed together.
- The red LED indicator will stop flashing and the iron will maintain this temperature whilst it is in use. If THE C9 TOUCH has not been used for 30 seconds it will automatically close down but once it is used again it will instantly reach the optimum working temperature.
- If you wish to lower the temperature to 165c for fine or delicate hair, quickly touch the plates together three times and the LED indicator will glow blue.
- If you wish to return to 195c for thicker wavier hair just quickly touch twice and THE C9 TOUCH will instantly return to the higher heat.
- Never wrap the cord around the iron even if it is cold.
- As with any electrical product do not use near water.
- THE C9 TOUCH is supplied with a standard two pin plug and has a UK three pin adaptor fitted. If you wish to use THE C9 TOUCH outside the UK simply remove the screw positioned in the centre of the plug and remove the adaptor from the two pin plug.

To see Cloud Nine's  
complete styling range please go to

[www.cloudninehair.com](http://www.cloudninehair.com)

  
**CLOUD NINE**<sup>®</sup>  
*Altogether kinder styling*

UNIL C9 LTD  
PO BOX 302, ILKLEY, LS29 1ET, UK

[www.cloudninehair.com](http://www.cloudninehair.com)

P-Touch QSL UK

UK

  
**CLOUD NINE**<sup>®</sup>  
*Altogether kinder styling*

THE C9 TOUCH Iron - smooth, flick, curl or straighten

Quick start  
and safety  
guide

## THE C9 TOUCH iron product features & warranty information

This product comes with a 12 month manufacturers warranty. In order to qualify for your 12 month manufacturers warranty you must activate it by registering your product on line at [www.cloudninehair.com](http://www.cloudninehair.com) within 14 days from date of purchase. This does not affect your consumer rights. Please read this section carefully before you use your new styling product. For full product information, styling hints, tips and to register your product or for help desk information, visit [www.cloudninehair.com](http://www.cloudninehair.com)



- 1) Fully Automatic
- 2) Instant Heat 195°
- 3) Quickly touch x 3 for 165°
- 4) Quickly touch x 2 for 195°
- 5) Dual Temperature
- 6) LED Temperature Indicator
- 7) Super-smooth Plate
- 8) Micom Control
- 9) 360° Swivel Chord

## THE C9 TOUCH iron product safety

Don't use your styling product near water.  
 Don't contaminate any part of your product with any chemical, hair colour or dye.  
 Don't use on wet hair.  
 Always unplug from the mains power supply immediately after use.  
 Clean your product by gently wiping with a damp lint free cloth, do not use sprays or detergents.  
 Never immerse your product in water and always switch off and unplug from the mains power supply before cleaning.

### General iron safety

Your iron can get incredibly hot so you really must be careful when using it.  
 Always closely inspect THE C9 TOUCH Iron for damage before you use it.  
 If the iron is damaged in any way do not use it. Instead go to our website for help desk contact details.  
 Do not touch the ceramic plates when the iron is switched on.  
 Keep hairsprays and styling aids at a safe distance away from your iron.

### Voltage

THE C9 TOUCH Iron can be operated with a mains voltage ranging from 200-240 Volts ac 50/60Hz, 40W.

### Operation Failure


If your styling product fails to work please follow this guide:  
 Check that your product and the power supply are switched on.  
 If your product, cable or plug become damaged in any way stop using it immediately and return your product to our service centre for repair.  
 Under no circumstances should you or anyone else tamper with the product as this will invalidate your warranty.

### Remember

It's important that you never use your styling product for anything other than styling hair as directed in the quick start guide. Your product has been specifically designed for this purpose and using the product for any other purpose could be dangerous.

### User Advice

Do not use excessive force when quickly touching the plates together as this may cause damage to the iron.  
 Please remember to keep your original proof of purchase in a safe place.  
 This product benefits from a 12 month manufacturers warranty, subject to terms and conditions.  
 This appliance can be used by persons aged from 16 years and above. If persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge use this product, an adult responsible for their safety must ensure that they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be carried out by children without supervision.  
 If the supply cord is damaged, it must be replaced by the manufacturer, or its service agent in order to avoid a hazard.  
 Cloud Nine THE C9 TOUCH C9-TI.0



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



This marking indicates that this product should not be disposed of with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.